

3D LED FAN

Model: Z30

User manual V3.3

Contents

| | |
|-----------------------------------|----|
| Foreword | 1 |
| Symbol description | 1 |
| Safety instruction | 1 |
| Product list | 2 |
| Product introduction | 3 |
| Product installation | 3 |
| Contents upload | 5 |
| Computer convert | 5 |
| Cell phone app convert | 6 |
| PC version software | 7 |
| Sound play | 8 |
| Remote control introduction | 8 |
| Device icon introduction | 9 |
| Make 3D video | 9 |
| Content library | 10 |
| More detailed operation | 10 |
| Specification | 11 |
| Failure analysis | 12 |
| Notes | 13 |
| Statement | 13 |
| Warranty card | 14 |

Foreword

Thank you for purchasing our 3D LED FAN,
please read user manual carefully before using it.

Symbol Description



Important note



Operation and use prompts

Safety Instruction



- The product works in a state of high speed rotation. Please do not disassemble or damage the protective cover to ensure personal safety.



- The installation position of the product must be firm, so as not to fall and hurt people.




- In case of collision, abnormal sound and other abnormalities, please stop using immediately.



- Users are not allowed to disassemble, repair or modify the product to avoid damage.

Product List

Before using this product, please check whether the product package is complete, if missing or damaged, please contact the purchasing dealer.



Host x1



Base x1



Base bracket x1



Wall Mount Bracket x1



Power adapter x1



Remote controller x1



Screws bag x1



Card reader x1



User manual x1


Non-slip silicone ring x2

Certificate of conformity x1



• Product and accessories drawings are schematic drawings. Due to product upgrade and update, there may be some differences between the actual object and the schematic drawings. Please refer to the actual product.

Product Introduction



① Cover

② Host

③ Base

④ Base Bracket

⑤ SD Card Slot

⑥ Power Port

⑦ Switch

⑧ Battery Pack


⑨ Speaker

Product Installation

First way, Wall-mounted


1 Drilling 4 Fixing Holes

Drilling 4 holes on the wall as diagram on the right.



2 Mount the Bracket

Mount the bracket on the wall by screws.(If it is fixed on the board, it can be fixed directly with self-tapping screws)



3 Connect the Power Cable

Connect the mainframe to the power supply and then hang it on the fixed bracket installed by the step two.



4 Fixed the Host

After the host machine is hung into the fixed bracket, it is pushed down and completely stuck into the limit slot to prevent the advertising machine from falling off and causing danger.



Second Way, Desktop


1 Install the Base Bracket

Align the base bracket to the hole under the base and push in gently so that the base can be placed vertically.




2 Install Base

Aim the base at the mounting hole on the back of the main engine, push it into the slot, and then push it up to get it completely stuck in the slot to prevent the advertising machine falling down.



2 Install Base

Aim the base at the mounting hole on the back of the main engine, push it into the slot, and then push it up to get it completely stuck in the slot to prevent the advertising machine falling down.



3 Connect the Power Cable


Insert the power supply into the power interface and turn on the back switch.



- The product works in a state of high speed rotation. Please do not disassemble or damage the protective cover to ensure personal safety.

Contents Upload

1. Computer Convert

After the video file is converted by using the transcoding tool "  XMediaRecode", copy to the TF card and it can be played normally.



- Video file format is complex and diverse, need to transcode to be able to play normally.
- TF card comes with this software of each 3D fan, please copy to the computer to use.
- Due to software upgrades and updates, please check the software user guide for detailed information.

2. Cell Phone App Convert

More functions and custom settings can be obtained through mobile APP for better experience. Scan the QR code below by mobile phone, or search '**3D LED FAN**' in the APP market, download and install APP.



- Android app market: Google, Huawei, Xiaomi, Vivo, Tencent myapp, Oppo, 360.
- Apple's app market: App Store.

① Connect the wifi hotspot of the device, click  Settings >  WLAN Find the wifi hotspot begin with product name (e.g. Z30_XXXXXX), enter the initial password 12345678(it is recommended to change the password after entering the APP).

② After successfully connected, some mobile phone will prompts 'The current WLAN is not accessible to the Internet, whether to continue using this WLAN?' Please click 'Yes'.

③ Open the APP and click the connected device in the 'Device List' to enter the operation interface. (Can format TF card, file operation, splicing video, splicing angle calibration, connect router, device updates and settings)





④ Click 'File Operation' to view existing files on the device, rename and delete files, select file playback, import files from album, 3D contents production and other operations.

⑤ Click 'Settings' to switch the device on and off with one key, modify WiFi name and password, adjust brightness/angle, bluetooth volume adjustment, playback mode settings, etc.

Single version: Support LAN content change, angle calibration and splicing/synchronization and other operations
(It is recommended to choose the 'Single version' when using a single device, which is more convenient to operate).

Network version: Based on the cloud server, remote splicing/synchronization of devices, cluster management and other operations.



- When the wifi connection fails, try to turn on the airplane mode, then turn on the wifi connection.
- When the iPhone cannot find the album in the software, click the phone's  settings <  3D LED FAN <  photos to set it as all the photos.
- Due to the upgrade and update of the app, the operation may be has tiny difference as the above description. For detailed functions and operations, please click the upper left corner  User Guide in the app to view.

3. PC Version Software

Download the PC version software via web:

<http://www.hologramfan.cn>, management software:

ADMachSys, ADMachSys supported features:



Single Version

No network cable is needed, and the LAN of the router is used for splicing/synchronization, angle calibration, content replacement and other operations.



Network Version

Based on the cloud server, remotely perform operations such as splicing/synchronization, cluster management, and content replacement of devices.



Device Configuration

Through the device configuration, the device can be bound to the router, modify the device hotspot, account binding and grouping operations.



File Cutting

When splicing devices, the file cutting function can be used to set the number of rows, columns, paths, machine models, etc., to do smart one-click cutting the content.




- Due to software upgrades and updates, detailed functions and operations, please click the user guide in the software to view.

Sound Play

When the content of the playback has sound, sound automatic reception, can have the sound.

- ① Upload animation with audio.
- ② Auto match, play sound.
- ③ The volume can be adjusted in the phone APP.

Remote Control Introduction



- If the play mode is set to be splicing mode, then only the A group can use remote control.

Device Icon Introduction



Device can not
read the TF card



There is no content
in TF card



Device system
is updating



Device is connecting
the router



Device system is
shutting down

Make 3D Video

Clients can make and DIY 3D video by themselves via our APP, it is very convenient.

Scan the QR code or click the link
<http://www.hologramfan.cn> to learn more about the
detailed operation guide.



Content Library

We provide varieties of 3d contents for different industry clients demand.

You can scan the QR code or check the following link
<http://www.hologramfan.cn>



More Detailed Operation

You can check the link <http://www.hologramfan.cn>, or scan the QR code to know more information.



Scan the QR code you will learn more.

Specification

| | |
|---------------------|-----------------------|
| Szie: | 315*315*50mm |
| Weight: | 1.61KG |
| Resolution: | 1024*256dpi |
| Led qty: | 2*128 |
| Viewing angle: | 170° |
| Rated power: | 12W |
| Voltage: | 12V |
| Rotating speed: | 1300r/min |
| Brightness: | 1200cd/m ² |
| Battery capacity: | 2200mAh (12V) |
| Communication mode: | 2.4G WiFi 802.11b/g/n |
| Bluetooth: | Yes |
| Multi splicing: | NO |
| Brightness adjust: | Yes |
| Angle adjust: | Yes |
| Remote control: | Multi-function |
| Timer on/off: | Yes |
| APP on/off: | Yes |
| TF memory: | 16GB |
| Content format: | MP4, AVI, RMVB, JPG |
| Upload method: | TF card/APP/Cloud/Web |

Failure Analysis

| Failure | Failure reason | Solution |
|---------------------------|--------------------------------------|--|
| Cannot boot | Power line no connect | Check whether the power line contact well |
| | Power failure | Check whether the power light on |
| Auto reboot | Wrong power adapter | Change an original power adapter |
| No display | TF card bad contact | Take off the TF card then boot the device, wipe up the TF card |
| | Video wrong format | Covert the video before send to TF card, or use the APP to send content to device |
| | TF card wrong format | Change the original TF card or format the TF card to fat 32 system, then re-download the content |
| Abnormal display | Led blades not install well | Re-install the LED blades make sure LED port fit the devices slot |
| | TF card wrong memory | Format the TF card, then download the content again |
| Light on but non-rotation | Software wrong operation | Contact service, use the TF card do factory reset |
| Vibration/ Noisy | Led blades not install well, or bend | Re-install the LED blades |

Notes

Tear down or remould

The product is made up of high density components, prohibit tearing down, repair, refit or hard fall to avoid damage.

Use and storage environment

- ① The normal operating temperature is 0°C~70°C, Please be carefully use it if out of this range.
- ② Do not use or storage it under high temperature, high pressure, strong magnetic field, dust and humidity.
- ③ It is recommended to use with the factory original protective cover.

Machine maintenance

- ① Do not use sharp objects to scratch on device surface.
- ② Please wipe with a soft dry cloth if there is dirt, stain or water droplets on device surface.
- ③ Do not use volatile organic solvents to clean the device surface, such as gasoline and alcohol.

Statement

Due to the upgrading and updating of the product, this manual is only for reference and does not constitute any form of commitment. The product (including but not limited to power supply adaptor, lamp beads, resolution, brightness, weight, material, function, etc.) shall be subject to the real object. In case of any inconsistency between this manual and the description of the real product, the real product shall prevail without further notice.

| WARRANTY CARD | | | |
|---------------|--------------------|--|----------------|
| User | Name: | | Product model: |
| | Invoice number: | | Purchase date: |
| | Address/Zip code: | | |
| Service | The date of repair | Failure description and handling information | Service person |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

* Under warranty, the product will get free repair if it be used normally. This warranty shall be rendered null&void if:

1. The product is physically damaged.
2. The product is installed, maintained and operated in ways not as recommended by us.
3. The product is faulty or damaged due to other occasional problem that not related to manufacturing.